



Master Rigid E


600x600, 1200x600, 1200x1200

M317




1. Ecophon Master Rigid E


2. Connect T24 Main runner



3. Connect T24 Cross tee,
L=1200



4. Connect T24 Cross tee,
L=600



5. Connect Adjustable hanger




6. Connect Hanger clip



7. Connect Hold down clip E



8. Connect Channel trim




9. Connect Direct fixing bracket



10. Ecophon Extra Bass 1200x600x50

Installation guide 317



Demounting
600x600 → **30**
1200x600 → **31**
1200x1200 → **32**




Ecophon[®]
SAINT-GOBAIN



A SOUND EFFECT ON PEOPLE



www.ecophon.com







600x600 → 3
1200x600 → 3
1200x1200 → 19




















600x600 → 10
 1200x600 → 15



600x600




10







11











14









































26



27





Demounting

600x600 →0

1200x600 →1

1200x1200 →2

