


Master Rigid Dp

600x600, 1200x600

M318



1. Ecophon Master Rigid Dp

2. Connect T24 Main runner

3. Connect T24 Cross tee,
L=1200

4. Connect T24 Cross tee,
L=600

5. Connect Adjustable hanger

6. Connect Hanger clip

7. Connect Wall bracket

8. Connect Shadow-line trim 0668




9. Connect Wall spacer 5

10. Connect Panel lock Dp

11. Connect Direct fixing bracket

12. Ecophon Extra Bass 1200x600x50



Installation guide 318







Ecophon[®]
SAINT-GOBAIN



A SOUND EFFECT ON PEOPLE



www.ecophon.com


























600x600 → 10
1200x600 → 17









1200x600

